



Chart Inc., 407 7th Street N.W., New Prague, MN 56071
Tel: 888-877-3093 Fax: 952-758-8293 E-mail: chart.sales@chartindustries.com

CryoVent Exhaust Gas Heater **PN 11797633**



The CryoVent Exhaust Gas Heater is designed to fit on the bayonet outlet of a Chart CryoVent. The heater keeps the CryoVent outlet frost-free. The heater is designed for indoor use in nitrogen service. The nitrogen vent gas is exhausted into the room, therefore the potential for an oxygen-deprived atmosphere must be considered.

Installation:

Slide the O-ring and the CryoVent Exhaust Gas Heater onto the outlet bayonet of a Chart CryoVent. (Heater can only be used with a bayoneted CryoVent, if a bayoneted CryoVent needs to be purchased contact Chart at the numbers above.) Preferably, position the electrical box at the 12:00 position. Connect the two bayonets together using the clamp provided with the CryoVent. Plug the cord into a 120 volt receptacle. The receptacle must be protected by a fuse or circuit breaker.



***Warning!* Due to large amounts of heat being distributed, the perforated metal will become hot. The 1" diameter circle directly above the heater will become extremely hot. DO NOT TOUCH!!!**

Operation:

The CryoVent Exhaust Gas Heater is made to run continuously. If not run continuously while nitrogen is flowing, frost and ice may form. For longest heater life, it is recommended that the heater is unplugged when the nitrogen system is shut down for extended periods.



Chart Inc., 407 7th Street N.W., New Prague, MN 56071
Tel: 888-877-3093 Fax: 952-758-8293 E-mail: chart.sales@chartindustries.com

During VIP system start up, the CryoVent can be isolated using Chart, CryoVent heater valve kit PN 11835572. After system start up is complete, the valve kit components must be removed. All pressure should be released before the valve kit components are removed.

If work or maintenance is being done around the CryoVent Exhaust Gas Heater caution should be taken to prevent being burned.

Hot Labels:

Hot labels are placed on the CryoVent Exhaust Gas Heater to provide caution to those working in the area. The hot labels are not placed directly at the hottest points due to the perforated metal. The hot point is directly above the heater and is about 1" in diameter. This part of the perforated metal will get hot. Therefore if work is to be done around the CryoVent Exhaust Gas Heater caution should be taken. Heater can also be unplugged if the risk of being burned is at hand. If heater is unplugged for extended periods of time frost and ice may form.



**Warning! Heater becomes extremely hot and will cause severe burns!
Do not put hand inside heater guard!**

Electrical requirement:

120 Volt AC – 1 Amp

Service:

Part Number	Description
3514751	V-band clamp
2322291	O-ring
11835572	CryoVent heater valve kit

If the CryoVent Exhaust Gas Heater needs service, contact Chart at the numbers listed above.