



Volume 9, Issue 1
Spring 2016

Quick Links

[Product Manuals](#)
[Industrial Surcharge Lists](#)
[Chart Website](#)
[Chart Field Service](#)
[Chart Parts](#)
[Chart Trainings](#)
[Distributor Marketing Services](#)
[Chart Used Tank Website](#)

NEW or UPDATED Literature Available

Chart has created or updated the following literature. Download copies at the following links:

[Perma-Cyl® 5500 VHP MicroBulk Storage System](#)
[MicroBulk Medical Skid](#)
[Mixed Gas Skid](#)
[Orca™ ST Series MicroBulk Delivery System](#)
[Nomad™ Mobile Bulk Tank](#)

Chart Vacuum Technology®



At Chart we have always taken pride in developing the best thermal insulation system possible in our cryogenic equipment. Chart Vacuum Technology is at the core of why Chart is recognized around the world as the premier supplier of cryogenic equipment.

Technical Service Questions?

There are many helpful people available to assist you with Industrial Gas Technical

NEW Econo-Cyl™ Liquid Cylinder

Built with our legendary Composite Super Insulation™ and Chart Vacuum Technology®, the Econo-Cyl liquid cylinder provides maximum gas utilization for your customers.



The Econo-Cyl liquid cylinder offers a thick stainless steel outer jacket, and all-metal shock absorbing footring, color-coded valve handles and color-coded safeties. The most popular models have been streamlined - making them the preferred choice in economical transportable liquid cylinders.

The highlights of this cylinder include:

- Four handling ring supports
- Integrated pull handle on 230 square base model
- 4" galvanized casters on 230 models
- Thick, dent-resistant outer shell

This unit is ideal for liquid nitrogen, oxygen, argon, CO₂ or nitrous oxide.

[View Econo-Cyl Liquid Cylinder Specification Sheet](#)

View [Design Change Notification DCN-101](#) for more details

Thermax Vaporizers

Chart Inc. is proud to have Thermax vaporizers included in our portfolio of products.



Thermax designs and fabricates the broadest line of vaporizers for cryogenic fluids and liquefied gases in the world. Vaporizer options include Ambient Air, Circulating Water, Electric, Fuel Fired, Steam and Water Bath Vaporizers.

For more information on how vaporizers can benefit your system please visit Thermaxinc.com today and click on the Vaporizers tab!

Service questions.

[Click here for a flyer](#) that describes our technical service abilities.

Design Change

Perma-Cyl[®] MicroBulk Storage System models have obsoleted the rubber stoppers on the pallet bases.

[Click here to view DCN-102](#)

Changing Faces at Chart



Scott Ceplecha has accepted the position of Customer Service Supervisor for the US and Canadian market.

Char Davis

has accepted the position of Inside Account Rep, South Region.



John Mushitz has accepted the position of Inside Account Rep, Airgas replacing Spanny Ceplecha

who will be retiring this month.

QUESTIONS?

We are only a phone call away!
800.400.4683



Matt Turek
Customer Service Dept.

Cryo Tip

OnSite Telemetry card in a Cyl-Tel[®] or

Tank-Tel[®] Liquid Level Gauge

Do you have a Chart Cyl-Tel or Tank-Tel unit with the Onsite telemetry card in it? Are you having trouble seeing the rear facing red light blink when you strike the magnet to force a cellular call to the OnSite website? If you have these issues, try temporarily removing the telemetry card from the unit and place a couple pieces of reflective tape or tape with a shiny surface along the back of the enclosure. Place the tape on the back so it is directly behind the area where the light is on the circuit board. Reinstall the circuit board. With the tape in place you can now see the reflection of the light when you strike that magnet. This is helpful for calibration and troubleshooting cellular board issues.



Jason Clark
Technical
Service Rep

Chart Upcoming Trainings



- Sept 7-8 [Bulk Tank Technical Training \(MN\)](#)
- Sept 20-21 [Beverage Technical Training \(GA\)](#)
- Sept 22 [Beverage Gen2 Training \(GA\)](#)
- Sept 27-28 [MicroBulk Technical Training \(GA\)](#)
- Sept 29 [Trifecta Technical Training \(GA\)](#)

[CLICK HERE TO VIEW TRAINING & REGISTRATION DETAILS](#)
www.chartuniversity.com



Chart Bulk Tank Tech Training New Prague, Minnesota May 2016

Upcoming Events

- Aug 28-31 IOA-PAG (Las Vegas) Chart Booth 12 & 13
- Sept 24-28 WEFTEC (New Orleans) Chart Booth 5343
- Sept 25-28 GAWDA (Kihei, HI) Chart Booth TBD

Chart's New Marketing Services Website Launching June 27

Chart's new and improved **Distributor Marketing Services Website** allows you to personalize brochures and specification sheets with **your** local contact information and company logo. It also allows you to order larger literature orders, customized posters, business cards, prospect generation, videos, images, and much more. This site is similar to our previous site, but is much more user-friendly for customizing and downloading documents. **At this time there is no cost to you.** We look forward to assisting your sales team!

Do you need to upgrade your marketing?

**Distribution & Storage
Distributor Marketing Services Website**

- ✓ Customized Literature
 - ✓ Download Images
- ✓ D&B Hoover's Leads
 - ✓ Customized Posters
- ✓ Software Sales Tools
 - ✓ Direct Mailers
- ✓ Business Cards
 - ✓ Product Videos



For more information, send an email to newprague.literature@chartindustries.com and note the subject as "Marketing Services Website Access".

Chart Tank Sizing App

The Chart Tank Sizing App provides assistance in the proper tank sizing of a gas account during a mode-change to cryogenic storage equipment by asking important inputs unique to the account and the gas supplier. The Chart tank sizing app is designed to work for Nitrogen, Oxygen, Argon and Carbon Dioxide service with one gas per sizing. From your Smart Phone or Tablet, use the appropriate link or QR Code to download the Chart tank sizing app today!

[**APPLE APP**](#)



[**ANDROID APP**](#)

