

## Cryogenic Liquid Cylinder Ambient Vaporizer Model D8A-3M

Liquid Cylinder Vaporizers increase vapor withdrawal rates for any type of Cryogenic Liquid Cylinder.



**Our Liquid Cylinder Vaporizer Installs in Minutes.**

**Our Vaporizers** can connect directly to the liquid withdrawal connection to economically boost withdrawal ratings.

**The model D8A-3M** will ensure that warm gas is there for your application.

### Standard Features

- ✕ New Megafin Model with 1200 SCFH rating for N<sub>2</sub>, O<sub>2</sub>, Ar (intermittent service)
- ✕ Each Unit is cleaned, sealed and tagged for Oxygen service.
- ✕ 600 PSIG MAWP standard.
- ✕ Compliant with ASME B31.3
- ✕ Carries CRN for all Canadian Provinces.
- ✕ Free Standing or hangs on your cylinder.
- ✕ Ships fully assembled, tested and ready to use.
- ✕ In stock and ready to ship

### Options

- ✕ Cryogenic Flex Hose
- ✕ Floor Mounted Drip Pan
- ✕ Pre-installed relief Valve with set points from 100 to 600 PSIG
- ✕ Stainless Steel lined
- EU/PED code compliance



Cryogenic Liquid Cylinder Ambient Vaporizer Model D8A-3M



Gas Outlet 1/2" FPT

Optional pressure relief valve

Your liquid cylinder with liquid shut off valve.

Vaporizer Liquid Inlet 1/2" FPT

Optional Cryogenic Flex Hose, LOX cleaned

Liquid withdrawal connection

Optional Floor mounted Drip Pan

## D8A-3M Vaporizer

### Typical Installation

